

## Routing Different Sources to Stryker Monitor

Justin Fedoryk - 2022-08-11 - AV/ Simulation IQ

Description: Steps on making sources in the Mock OR and Control Room for the Mock OR display on the Stryker Monitors.

1. **From the Home Screen of the Crestron Touch Panel in the Control Room: Select "EMR Inputs"**



2. **Once your Source is selected, Select the monitor you would like to see it on.**

**(The selected display will now be highlighted)**

\*You can select multiple monitors or "Vitals" on one and "EMR" on the second\*