

<u>Knowledgebase</u> > <u>Simulation</u> > <u>Technical Materials</u> > <u>AV/ Simulation IQ</u> > <u>Routing Different Sources to Stryker</u> <u>Monitor</u>

Routing Different Sources to Stryker Monitor

Justin Fedoryk - 2022-08-11 - AV/ Simulation IQ

Description: Steps on making sources in the Mock OR and Control Room for the Mock OR display on the Stryker Monitors.

1. From the Home Screen of the Crestron Touch Panel in the Control Room: Select "EMR Inputs"



There are two Stryker Routing Options ("Vitals", "EMR") ->Select the Source you would like to be displayed

If you only need one source, you can ignore the "EMR Source" or just make both ("Vitals" and "EMR") the same.

*If the screen is not at the home screen like in "Step: 1" you can select "EMR Inputs" at the bottom from any other screen to get here"

Control Room		Control Room	
Manikin PC		Manikin PC	
Nurse Station		Nurse Station	
Dill Input		DM Input	
Anesthesia		Anesthesia	
In-Light Camera		In-Light Camera	
Endo Cam		Endo Cam	
Stryker		Skryker	

3. From the Stryker Screen: Select the Source ("Vitals" or "EMR") you want to display (The Source should be highlighted after selecting)



4. Once your Source is selected, Select the monitor you would like to see it on.

(The selected display will now be highlighted)

You can select multiple monitors or "Vitals" on one and "EMR" on the second



5. The Source should now be displaying on the monitor(s) of choice

Verify that the monitors are on and functioning